thermoscientific

PRODUCT SPECIFICATIONS

Thermo Scientific 111iQ

Zero Air Supply—designed for NO, NO₂, O₃, SO₂, CO and hydrocarbon requirements



The Thermo Scientific™ 111iQ
Zero Air Supply uses an external compressor; the pressure regulators, chemical scrubbers, reactor and temperature controller are all contained in a single convenient case.

Designed for any application where pollutant free levels of NO, NO₂, O₃, SO₂, CO and hydrocarbons are required, with flows up to 20 liters per minute at pressure of 30 PSI.

The room air enters the compressor, where it is raised to a pressure of 80-90 PSI. The output of the compressor contains a coalescing filter and a pressure regulator where the pressure is reduced to 70 PSIG.

The air then passes into a column of Purafil (potassium permanganate on alumina) which oxidizes NO to $\mathrm{NO_2}$. From there the air passes through a column of activated charcoal which removes $\mathrm{NO_2}$, $\mathrm{SO_2}$, $\mathrm{O_3}$ and hydrocarbons.

Lastly, the air then goes into the reactor where it is heated to 350°C over a catalytic surface which converts CO to CO_2 and any remaining hydrocarbons, including methane, to water and CO_2 . This process results in a pollutant free stream of air.





thermoscientific

Thermo Scientific 111iQ Zero Air Supply

Specifications		
Approvals and certifications	ETL, CE	
Compressor size & weight	20" (D) x 12" (W) x 17" (H), 40 lbs 508 mm (D) x 304.8 mm (W) x 431.8 mm (H), 18.14kg	
Converter temperature	325°C - 450°C	
Flow Rate options	0-10 LPM 0-20 LPM	
Mounting options	Rack mounting, table top	
Operating temperature	0°C - 45°C	
Physical dimensions	24 in (D) x 16.75 in (W) x 8.72 in (H) 609 mm (D) 425.45mm (W) x 221.48 mm (H)	
Pollutant concentration levels	CO < 0.1 ppm HC < 0.1 ppm NO < 0.5 ppb NO ₂ < 0.5 ppb	SO ₂ < 0.5 ppb
Power requirements	115–240 VAC 50/60 Hz 120–190 W	
Pressure	10-30 PSI	
Storage temperature	-20°C - 60°C	
Water vapor	0°C Dew point	
Weight	22 lbs (9.98kg)	


Ordering information 111iQ Zero Air Supply

Title Ectoral Cappiy
Choose from the following configurations/options to customize your own 111iQ
1. Nominal Supply Voltage and Frequency
N = No Power Requirements
A = 120 VAC 50/60 Hz (NA)
B = 220 VAC 50/60 Hz (EU)
D = 220 VAC 50/60 Hz (CHN)
2. Compressor sizes
N = No Compressor
1 = 10 LPM Compressor
2 = 20 LPM Compressor
3. CO reactor
N = No CO Reactor
1 = 1 Reactor

Your Order Code: 111iQ



Flow diagram: 111iQ



USA

27 Forge Parkway Franklin, MA 02038 Ph: (508) 520-0430 Fax: (508) 520-2800 orders.aqi@thermofisher.com

India

C/327, TTC Industrial Area MIDC Pawane New Mumbai 400 705, India Ph: +91 22 4157 8800 india@thermofisher.com

China +Units 702-715, 7th Floor

Tower West, Yonghe Beijing, China 100007 Ph: +86 10 84193588 info.eid.china@thermofisher.com

Europe

Ion Path, Road Three, Winsford, Cheshire CW73GA UK Ph: +44 1606 548700 Fax: +44 1606 548711 sales.epm.uk@thermofisher.com

Find out more at thermofisher.com/111iQ thermofisher.com/iQSeries

